


Airbag Warning Light Illumination Pattern

AIRBAG SYSTEM (TYPE B) (DIAGNOSTICS)

10. Airbag Warning Light Illumination Pattern

A: INSPECTION

Turn the ignition switch to ON, and confirm that the airbag warning light remains on for approx. 6 seconds then turns off afterwards.



- (1) Airbag warning light
- (2) Approx. 6 seconds
- (3) Ignition switch ON