


Electrical Component Location

OCCUPANT DETECTION SYSTEM (TYPE B) (DIAGNOSTICS)

4. Electrical Component Location




A: LOCATION



(1) Occupant detection control module


(2) Occupant detection sensor
(3) Seat belt tension sensor

(4) Buckle switch (Passenger's seat)



Electrical Component Location

OCCUPANT DETECTION SYSTEM (TYPE B) (DIAGNOSTICS)



(A) For US model

(B) For Canada model

(1) Passenger's airbag OFF indicator light

(2) Passenger's airbag ON indicator light